












Geberit Montage








D8334-002&BDC © 08-2005

964.152.00.0 (02)

Geberit Montage








Geberit Montage



Geberit Montage



Aufputz Spülkasten
Surface-mounted cistern
Réservoir de chasse apparent
Cassetta di risciacquamento esterna








■ GEBERIT


Geberit Montage









Unterputz Spülkasten
 Concealed cistern
 Réservoir de chasse encastré
 Cassetta di risciacquamento ad incasso




Geberit Montage









Unterputz Spülkasten
 Concealed cistern
 Réservoir de chasse encastré
 Cassetta di risciacquamento ad incasso



Geberit Montage



Wand-WC mit UP-Spülkasten für Betätigung von oben / von vorne
 Wall hung WC with concealed cistern, top / front-operated
 WC suspendu avec chasse d'eau à encastrer pour déclenchement dessus / devant
 Vaso sospeso con cassetta di cacciata incassata da azionare dall'alto / da davanti



■ GEBERIT